

Programming Your Trailerteck Wireless Remote Control

A remote control can be programmed very quickly in a few easy steps.

- 1. Make sure the device is turned off
- 2. Press and hold the ON/OFF button on the control panel for approximately 5 seconds until the ON/OFF light starts to blink.
- 3. Release the ON/OFF button
- 4. Press the red button (PROG) on the remote and release
- 5. The remote is now programmed



